


PATRIOT™ DB INSTALLATION GUIDE



Congratulations on your purchase of the PATRIOT DB!
The following seven steps will guide you in installing your system in just a few minutes.

A photograph of a PC case with the front panel removed. A red circle highlights the drive bay area on the back of the case.	<p>Turn PC Power Off</p> <p>STEP ONE: Open your PC</p> <p>STEP TWO: Remove the 5.25 inch face plate from the front of your PC, and then remove one of the expansion slot covers on the back.</p>
A close-up photograph of the Patriot DB device installed in a PC case. Red circles highlight the power and USB connections on the back of the device.	<p>STEP THREE: Insert the PATRIOT DB into a drive bay slot and secure using either the screws provided by Polhemus or the plastic inserts provided by the PC manufacturer</p> <p>STEP FOUR: Plug the PC power and the USB cable in to the back of the PATRIOT.</p>

	<p>NOTE: If the power plug from the PC doesn't match the PATRIOT Molex plug, please use the SATA to Molex Power Adapter provided.</p>
	<p>STEP FIVE: Insert the USB cable through the expansion slot and plug directly into one of your PC's USB ports.</p>
	<p>STEP SIX: Close and power up your PC.</p> <p>STEP SEVEN: Insert your PATRIOT installation software tool kit and manual CD and follow prompts for installation of new hardware and Polhemus software and manual.</p>

MS082 MARCH 2010